

HP's USB Warranty Date Distinguish

☀ HP logo USB that only to provide customers **two years warranty.**

☀ The First Version



The second code :

This code indicates the year of production.

The code defined as follows:

"8"=2008, "9"=2009, "0"=2010, "1"=2011

The third code :

This code indicates the month of production.


The code defined as follows:

"1"=January, "2"=February, "3"=March, "4"=April, "5"=May, "6"=June,

"7"=July, "8"=August, "9"=September, "A"=October, "B"=November, "C"=December



☀ The Second Version



The first code :

This code indicates the year of production.

The code defined as follows:

"A"=2010, "B"=2011, "C"=2012, "D"=2013...

The second code :

This code indicates the month of production.

The code defined as follows:

"J"=January, "F"=February, "M"=March, "A"=April, "Y"=May, "E"=June,

"U"=July, "G"=August, "S"=September, "O"=October, "N"=November, "D"=December

The third code : This code indicates that the capacity.



☀ Please first according to that end-user's the date of purchase that starting two year warranty.
If the proof of purchase is lost then will according to the date of starting production.

☀ Does the out of warranty, PNY will be based on the date of receive as a benchmark.